



Figure 1 - Adapter Boards Connections

- 1) Make sure the JTAG adapter board connector is centered inside the shrouded header (J2) on the Flyswatter.
- 2) Make sure the JTAG and RS232 cables are oriented as shown in Figure 1.